



Getting Started With Your Project-A-Phone Flex

Paraben's Project-A-Phone Flex™ comes with two cameras - one for use with a PC and one for portable use. The first thing to do is set up your unit on a flat surface like a counter or table no more than 2" thick to attach your Flex arm. Lay down your Flex mat then connect the clamp over top of the mat to secure it in place. Next, connect the arm to the clamp. Then connect the camera bracket to the arm. You can now mount either camera to the bracket and position the arm and bracket so the camera points to the area on the mat to be captured.

You may also choose to use the portable camera without the mount to capture images of other types of evidence associated with your case to be imported into your report at a later time. A 4 GB SD card is included with your Flex to facilitate this.



Using the PC Camera:

- ▶ The PC USB camera functions best when used with the native LifeCam software to take images up to 8 MP and HD video. Please note that the Case Reporting Software will not run properly while the LifeCam software is running. Once you capture your video and/or images with the LifeCam software, you can create a final report in the Case Reporting Software by importing the images and video into your report and making any notes or comments in your report.

Using the Portable Camera:

- ▶ The portable point-and-shoot camera can be used either with the Flex arm or separately out in the field. Once you have images and/or video captured on the camera, simply transfer them to the PC. Once on your computer, open the Case Reporting Software and import the files into your report.

Using the Case Reporting Software:

- ▶ Once you open the case reporting software, click on the "Browser" tab to start a new report. Please note that the "Monitor" tab will display the PC camera image if it is attached. The case reporting software is designed to capture images and video from the Project-A-Phone ICD-5200. It cannot capture images from your PC camera but can capture video. We recommend you use the native LifeCam software to capture all videos and images.

After clicking the "Browser" tab, click "Add New Case ID" to start a new report. Click "Add Files to Case" and browse for the images to add either from the USB camera or portable camera. You can also load other pertinent files to your case. Fill out your "Case" and "Phone" information. Next, click the "Evidence" button to add notes to individual files and to add files to your report. You can upload a custom logo, set the size of images in the report, and create your final report under the "Report" tab.

Be sure to check out our entire line of StrongHold signal blocking faraday technology to protect your evidence from unwanted wireless signals: <http://www.paraben.com/stronghold.html>



Phone: 801.796.0944
Fax: 801.796.0610
Web: www.paraben.com